


Available Control Modules	
Catalog Number	Instantaneous Pickup, Amperes, RMS
811050	5 000
811060	6 000
811080	8 000
811100	10 000
811120	12 000

Important: S&C Fault Fiter Electronic Power Fuse Control Modules must be selected by qualified persons who are knowledgeable in the subjects of equipment protection and time-current coordination, and who understand the consequences of improperly coordinated overcurrent protective devices. Failure to achieve complete coordination between Fault Fiter Electronic Power Fuses and source-side or load-side protective devices may result in improper operation of one or more Fault Fiter Fuses.



Note: For maximum peak let-through current curves and let-through I²t curves, refer to S&C Data Sheets 440-205 and 440-206, respectively.

Note: Curve pairs represent minimum tripping and total clearing characteristics.

Printed in U.S.A.

